

Team Z Motorsports

Solid Motor Mount installation instructions

Parts Included:

2-Solid Motor Mounts

Optional-Heavy Duty Bolt Kit

1. Jack up front of vehicle and place firmly on jack stands.
2. Remove front wheels



3. Remove nuts (1 each side) from the bottom of the motor mounts.



4. Use an engine support beam or a piece of wood on a floor jack to raise the engine high enough to get the motor mount stud out of the k-member.



5. Remove the 2 bolts holding the mount to the engine.



6. Bolt the solid mounts to the engine block.
7. Slowly lower the engine down. Paying close attention to lining up the holes in the k-member and the holes in the motor mounts.



8. Get the bolts through the k-member started before engine is resting on the k-member.
9. Once bolts are started lower the engine completely.
10. Verify engine is sitting in the correct location and level before tightening the bolts.
11. If you are using the drop motor mounts check the fan and other items that may be affected by lowering the engine.
12. Reinstall wheels and torque lug nuts.